

IRED RECEIVER WIRING DIAGRAM

ATTENTION

- the first relay switches on after using the first button of transmitter (P1)
- the second relay switches on after using the second button of transmitter (P2)
- the third relay switches on after using the third button of transmitter (P3)



